

HOW TO CHECK BATTERY LEVEL ON AUTOMATE MOTORS

Quick Guide

Follow the process below to quickly determine how charged a shade battery is on an EcoSmart Roller Shade *without* the Automate app.

Steps

1. Bring Shade to Upper Limit

1. The shade must be at the upper limit before beginning this check




Figure 1

2. Prompt Shade

1. On the Rollease Acmeda remote (PUSH 1, 5, 15, PRO), hold the **UP** button for approximately 5 seconds




Figure 2

3. Shade Sent to Battery Charge Level

1. The shade will move down and stop at the percent of battery charge remaining. See Figure 2




Figure 3

See also:

Automate | Zero Battery | Check Function. (2020, September 28)

https://youtu.be/Mj08tYy0hs?si=nJUuVQ8W01Kr_FkO